



INSTRUCTION MANUAL

"NOTE: Hoverboard not included

ATTENTION:

- 1. When riding the Hoverkart, ALWAYS wear a safety helmet, gloves, knee & elbow pads.
- 2. When riding the Hoverkart, please do so in an open, quiet area, being mindful of others around you. DO NOT RIDE in areas where there are motor vehicles and in areas that could potentially be hazardous. Always be observant and ride with care.
- 3. DO NOT USE the Hoverkart on unstable surfaces. DO NOT USE the Hoverkart on slopes or descents greater than 30°. The Hoverkart and hoverboards are not legally permitted on public roads.
- 4. DO NOT RIDE too fast or make sudden turns. DO NOT tilt the Hoverkart upwards while riding as this action could cause injury.

ATTENTION: Different hoverboards do have a variety of settings. To turn off the hoverboard, in some instances, it may be necessary to loosen the straps & slightly raise the kart. Please be extremely careful when lowering the kart when the unit is switched on, as moving the handlebar will cause the kart to move.

Now you can enjoy your GoHoverkart Hoverkart. Simply sit in the seat, raise your feet, placing on the foot support. Before setting off, look around you to make sure the area is clear and that you are safe to turn on the hoverboard. Take care to follow the instructions to perform the directional movements. Now you are set to go!

Monster Hoverkarts are imported and distributed by National Deals Limited.

60 Dudley Road East, B693HJ, Oldbury United Kingdom

Email: hi@nationaldelas.co.uk

National Deals Limited Declaration of conformity:

National Deals Limited declared the equipment meets the requirements indicated in the following directives:-

EN71-1:2014 EN71-2-2011+AI:2014 EN71-3-2013+A1:2014

Declaration of conformity: ESN ISO 12100:2010 ESN ISO 13857:2008

USER CARE GUIDE

Hoverkart helps you to transform your hoverboard into a seated, stable three-wheeled vehicle. The Hoverkart can be used for various size hoverboards, engaging the attached belt/strap. The Hoverkart has an adjustable bar, to suit a variety of ages and sized riders.

RIDING METHOD:

Moving Forward & Backward:

Sit on the Hoverkart. Using both hands, hold the operating handles, pressure forward at the same time, the kart will move forward. When you want to brake, pressure in the reverse to aid stopping the Hoverkart.



Turning Left & Right:

To turn right, the left handle should be in the lowered position and the right handle should be in the raised position.

To turn left, the right handle should be in the lowered position and the left handle should be in the raised position.



MAINTENANCE FOLLOWING EACH USE:

Clean the Hoverkart removing dirt and debris with a soft, damp cloth. Dry the Hoverkart when wet. Store the Hoverkart indoors in a dry area. Do not store the Hoverkart outdoors or subject to direct sunlight & UV rays, for a long period.

ASSEMBLY GUIDE

CONTENTS:



Parts:

- 1. Hoverkart Wheel
- 2. Seat
- 3. Chassis Extender

- 4. Main Chassis
- 5. Control Handles
- 6. Hoverboard straps



Fixings & Tools:

- A Long bolts
- B Big Washers
- C Spanner
- D Nuts big
- E Allen Key
- F Nuts small
- G Small Washers
- H Small bolts

ASSEMBLY INSTRUCTIONS:

Step 1.

Attach Control Handles (5) to the rear of the main chassis (4) with Long Bolts (A) & Nuts (D) using Allen Key (E) and Spanner (C).



NOTE: Ensure Control Handles are attached curving outwards away from the center (see fully assembled image for reference).



Attach Seat (2) to seat plate of main chassis (4) with Small Bolts (H), Small Washers (G) & Nuts (F) using Allen Key (D).



Step 3.
Insert Chassis
Extender (3) into Main
Chassis (4)



Step 4.

Attach the wheel (1) to the end of the chassis extender (3) using Long bolts (A), Big washers (B) & Nuts (D) using the Spanner (C) and Allen Key(E).



Step 5.

Attach Hoverkart to a hoverboard under the seat using the Adjustable Straps (6).



NOTE: Hoverboard to included.

Fully Assembled Hoverkart with Hoverboard:



2